

Figure 1




FIGURE 2




FIGURE 3




Figure 4




Figure 5




FIGURE 6

Figure 7

700





FIGURE 8



800




FIGURE 9

Message Router 25000




FIGURE 10




FIGURE 11

Route Path Determination 25200




FIGURE 12




FIGURE 13

Storage System 17000





FIGURE 14



Sync System 17100




FIGURE 15

Self Configuring Network 16100






FIGURE 16

Command Scenarios 15000



On Message
(msg = true)
27001



On Command
Scenarios Init.
15001





FIGURE 17

Self Configuring Command and Control 15100

FIGURE 18






FIGURE 19




FIGURE 20




FIGURE 21




FIGURE 22




FIGURE 23




FIGURE 24




FIGURE 25

Keyword Scenarios

14000




FIGURE 26

UI Parser 18000




FIGURE 27

Graphical UI 18100

On Message
(msc = true)
27001




FIGURE 28

Text UI 18200




FIGURE 29

Audio UI 18300




FIGURE 30

GUI Unit Update 18400




FIGURE 31

GUI Env Update 18500




FIGURE 32